

SPARK BUSINESS GROUP

Email: enquiry@sparkbusinessgroup.com.au Website: sparkhomes.com.au Unit 3, 13 McCormack Street, Arndell Park, 2148 NSW

Telephone: (02) 88074717, (02) 86787856

Sparkhomes.com.au

Installation guide for Add-A-Bathroom standard 8 panel flat pack bathrooms.

Please read the entire guide prior to commencement of assembly or installation.

Note that this guide is provided for general information purposes only and should not be relied upon without professional advice about your personal situation and installation requirements. As this guide does not take personal circumstances or local regulations into account and as any installation is beyond the control of Spark Business Group no responsibility is accepted nor warranty implied by Spark Business Group (or its affiliated entities) by the publishing or use of this guide.

Spark Business Group flat pack bathrooms are manufactured in our modern production facilities and are supplied ready for assembly and installation.

Follow this simple guide and your Spark Business Group bathroom should give you many years of trouble free service. No leaks, no cracks, no maintenance.

No specialised tools are required to install an Spark Business Group flat pack bathroom. Installation of a bathroom usually requires 2 competent people.

All plumbing and electrical work must be performed by appropriately licensed contractors.

Flat pack bathrooms are normally supplied as 8 panels with pre-drilled bolt holes and fasteners. Before commencing installation open packaging and ensure all items are correct and in acceptable condition. No claims regarding damage or missing components can be entertained after assembly commences.

(If you have sufficient access to receive and manoeuvre an assembled bathroom, the bathroom can be supplied fully assembled ready for installation. Please contact Spark Business Group for details.)

Line up, identify and label all panels so as to facilitate assembly. Check quantity of nuts, bolts, washers etc. Ensure sufficient suitable sealant is available; this may be included with your bathroom depending upon individual order.

Clean and maintain your new Spark Business Group bathroom with domestic grade non-abrasive cleaning agents. Walls may be polished with automotive or marine polishes suitable for use on fibreglass. Ensure polishes, silicone washes, waxes and the like are kept away from any bathroom floor as such products may be slippery.