



SPARK BUSINESS GROUP

Email: enquiry@sparkbusinessgroup.com.au Website: sparkhomes.com.au
Unit 3, 13 McCormack Street, Arndell Park, 2148 NSW
Telephone: (02) 88074717, (02) 86787856

Sparkhomes.com.au

TYPICAL ASSEMBLY AND INSTALLATION DRAWINGS

Panels, sizes and waste locations vary between units.

*Note: Poor or inadequate installation of sealant may be the cause of leakage. Do it right the first time.
Please read the sealant use guide provided.*

Sequence of panel assembly for all standard 8 panel, smooth look flat pack bathrooms.

For tiled look models the two back panels (panels 3 and 4) are vertical; the assembly sequence is the same.

The initial beads of sealant to be applied in the shower areas are indicated by the coloured lines and the letters C,E,H,P; referencing the relevant section of the assembly guide instructions. Should local requirements dictate a fully sealed room (which would be unusual) all joins (other than the ceiling) may require to be so sealed.

