



SPARK BUSINESS GROUP

Email: enquiry@sparkbusinessgroup.com.au Website: sparkhomes.com.au
Unit 3, 13 McCormack Street, Arndell Park, 2148 NSW
Telephone: (02) 88074717, (02) 86787856

Sparkhomes.com.au

Floor waste installation instructions.

Apply silicone sealant to the underside of the top flange of the floor waste.

Fit rubber washer and rear collar provided to the under side of the bathroom floor and fit back nut to the floor waste and hand tighten. Do not over tighten.

